



3. Cut out the template.

FRONT

- Stick it onto the bench top so that the dashed outlines sits at the same distance from the known points (i.e. directly above the toilet base).
- 5. Cut out the inner hole following the solid line.



## TEMPLATE B: LID

Version:1Released:25 February 2022Product code:P-22